solano® BLOW DRYER | CARE & MAINTENANCE

Dryer and concentrator nozzle
Secador y boquilla concentradora

Switches
Interruptores

Removable filter ring and screen
Anillo y rejilla del filtro desmontables

Disassembled filter ring and screen
Filtro y rejilla desmontados

OPERATING INSTRUCTIONS

1. This dryer can be used in various countries. Before using your new hair dryer check that the power supply voltage corresponds with that shown on the dryer. You may need a converter plug, sold separately.
2. Reference the Switch Settings for optimum dryer performance.
3. The styling nozzle serves to concentrate the airflow and work smaller sections of hair.
4. Your dryer will have either a stationary or removable filter system. The filter ring and screen allows you to keep your appliance free from entrapped hairs and dust. A quarter turn to the left disconnects the removable filter ring and screen from the dryer. Remove the filter screen and clean it with a brush. Replace the filter ring and screen by turning to the right. Remember to clean your filter regularly.
5. For your safety, your hair dryer is equipped with a thermal-protective switch, which prevents damage by overheating. In the event of overheating the thermal-protective switch will interrupt the heating element and stop heating. The dryer must be unplugged from the power supply and the filter screen cleaned. After the dryer has cooled, it can be turned back on.
6. The front air outlet grill can become very hot. Do not touch this grill and make sure that the power cord does not come in contact with this area.

IMPORTANT

1. This appliance must be repaired by a qualified Solano electrician only.
2. This appliance must never be immersed in water.

INSTRUCCIONES DE OPERACIÓN

1. Este secador puede utilizarse en varios países. Antes de utilizar su nuevo secador, asegúrese de que el nivel de suministro de voltaje corresponde al que aparece en el secador. Es posible que necesite un tomacorriente convertidor, el cual deberá comprar por separado.
2. Remítase a las indicaciones sobre las posiciones de los interruptores para el desempeño óptimo del secador.
3. La boquilla desmontable sirve para concentrar el flujo de aire y secar secciones de cabello más pequeñas.
4. Su secador tiene un sistema de filtro fijo o uno desmontable. El anillo y la rejilla del filtro le permiten mantener su aparato libre de polvo y restos de cabello. Un cuarto de vuelta a la izquierda separa la rejilla de entrada y el filtro. Saque la rejilla y límpiela con un cepillo. Coloque de nuevo el anillo y la rejilla con un movimiento giratorio hacia la derecha. Recuerde que debe limpiar el filtro con frecuencia.
5. Para su protección, su secador está equipado con un termostato protector que previene el daño por recalentamiento. Si el aparato se llegara a recalentar, el termostato interrumpirá inmediatamente el suministro de calor. Desconéctelo del tomacorriente, limpie la rejilla y enciéndalo nuevamente una vez se haya enfriado.
6. La rejilla frontal del secador puede llegar a calentarse excesivamente. No toque esta rejilla y asegúrese de que el cable de la corriente no entre en contacto con esta área.

IMPORTANTE

1. Este aparato deberá ser reparado únicamente por un electricista calificado de Solano.
2. Este aparato nunca deberá sumergirse en el agua.

SWITCH SETTINGS

POSICIONES DE LOS INTERRUPTORES